

WINDOW FLASHING


Based on

AAMA Method “A”

Condition: The window is installed **before** the building paper is applied.

WINDOW FLASHING METHOD “A”

Step 1




Step #1

- Install sill flashing extending 4” beyond the rough opening on each side.
- Do not attach the bottom of the sill flashing. This will allow the building paper to be installed beneath the sill flashing in step #5.

WINDOW FLASHING METHOD "A"

Step 2




Step #2

- Apply a continuous bead of caulking on the back side of the window flange.
- Install the window over the sill flashing and according to the manufacturers specifications.
- Do not attach the bottom of the sill flashing. This will allow the building paper to be installed beneath the sill flashing in step #5.

WINDOW FLASHING METHOD "A"

Step 3




Step #3

- Install jamb flashing over the window flange on each side.
- Install the jamb flashing even with the bottom of the sill flashing.
- Extend jamb flashing 4" above the rough opening.
- Do not attach the bottom of the sill flashing. This will allow the building paper to be installed beneath the sill flashing in step #5.

WINDOW FLASHING METHOD "A"

Step 4




Step #4

- Install head flashing over the window flange and the jamb flashing.
- Extend the head flashing 8" beyond the rough opening.
- Do not attach the bottom of the sill flashing. This will allow the building paper to be installed beneath the sill flashing in step #5.

WINDOW FLASHING METHOD "A"

Step 5




Step #5

- Install building paper beneath the unattached portion of the sill flashing.
- Finish attaching sill flashing to the building paper.
- Do not attach the bottom of the sill flashing. This will allow the building paper to be installed beneath the sill flashing in step #5.

WINDOW FLASHING METHOD "A"

Step 6




Step #6

- Continue installing building paper from the bottom to the top wall.
- Install the building paper over the flashing and window flange fitting tightly against the window frame.
- Overlap building paper by a minimum of 3".

WINDOW FLASHING METHOD "A"

Step 7



Step #7

- Continue installing building paper from the bottom to the top wall.
- Install the building paper over the flashing and window flange fitting tightly against the window frame.
- Overlap building paper by a minimum of 3".